



CTC (Chlortetracycline) ELISA Kit

Catalog No: E-FS-E024

96T

This manual must be read attentively and completely before using this product.

If you have any problems, please contact our Technical Service Center for help.

Phone: 240-252-7368(USA) Fax: 240-252-7376(USA)

Email: techsupport@elabscience.com

Website: www.elabscience.com

Please kindly provide us the lot number (on the outside of the box) of the kit for more efficient service.

Test principle

This kit uses Competitive-ELISA as the method. It can detect Chlortetracycline (CTC) in samples, such as meat, honey, eggs. This kit is composed of ELISA Microtiter plate, HRP conjugate, antibody working solution, standard and other supplementary reagents. The microtiter plate in this kit has been pre-coated with coupled antigen. During the reaction, CTC in the samples or standard competes with coupled antigen on the solid phase supporter for sites of anti-CTC antibody. Then Horseradish Peroxidase (HRP) conjugate is added to each microtiter plate well, and substrate reagent is added for color development. There is a negative correlation between the OD value of samples and the concentration of CTC. The concentration of CTC in the samples can be calculated by comparing the OD of the samples to the standard curve.

Technical indicator

Sensitivity: 0.1 ppb

Reaction model: 37°C, 30 min~30 min~15 min.

Detection limit: Meat, Liver, Eggs ---0.8 ppb; Honey ---4 ppb; Urine ---1 ppb

Cross-reactivity: Chlortetracycline ---100%, Tetracycline ---29%, Oxytetracycline ---15%,
Doxycycline ---2.5%

Sample recovery rate: Meat, Liver, Eggs ---90% ± 20%; Honey ---75% ± 20%; Urine ---80 ± 20%

Kits components

Item	Specifications
ELISA Microtiter plate	96 wells
High Concentrated Standard (1.0 ppm)	1 mL
Standard Liquid (empty bottles)	0 ppb, 0.1 ppb, 0.3 ppb, 0.9 ppb, 2.7 ppb, 8.1 ppb
HRP Conjugate	11 mL
Antibody Working Solution	5.5 mL
Substrate Reagent A	6 mL
Substrate Reagent B	6 mL
Stop Solution	6 mL
20×Concentrated Wash Buffer	40 mL
5×Reconstitution Buffer	50 mL
Plate Sealer	3 pieces
Sealed Bag	1 piece
Manual	1 copy

Note: All reagent bottle caps must be tightened to prevent evaporation and microbial pollution.

Other materials required but not supplied

Instruments: Microplate reader, Printer, Homogenizer, Centrifuge, Graduated pipette, Balance (sensitivity 0.01 g).

Micropipette: Single channel (20-200 μL , 100-1000 μL), Multichannel (30-300 μL).

Reagents: Trichloroacetic acid.

Experimental preparation

Restore all reagents and samples to room temperature before use.

Open the microplate reader in advance, preheat the instrument, and set the testing parameters.

1. Sample pretreatment Notice:

Experimental apparatus should be clean, and the pipette should be disposable to avoid cross-contamination during the experiment.

2. Solution preparation

Please prepare solution according to the number of samples. Don't use up all components in the kit at once!

Solution 1: 1% Trichloroacetic acid Solution

Dissolve 1 g of **Trichloroacetic acid** to 100 mL with deionized water.

Solution 2: Reconstitution Buffer

Dilute the **5 \times Reconstitution Buffer** with deionized water. (5 \times Reconstitution Buffer (V): Deionized water (V)=1:4). The Reconstitution buffer can be stored at 4 $^{\circ}\text{C}$ for a month.

Solution 3: Wash Buffer

Dilute **20 \times Concentrated Wash Buffer** with deionized water. (20 \times Concentrated Wash Buffer (V): Deionized water (V) = 1:19).

3. Sample pretreatment procedure

Substance in sample is distributed unevenly. It is recommended that more samples should be taken when sampling.

3.1 Pretreatment of tissue (livestock, shrimp, fish) liver, eggs sample:

- (1) Weigh 2 ± 0.05 g of homogenate samples into centrifuge tube. Then add 4 mL of **1% Trichloroacetic acid Solution** (Solution 1) to centrifuge tube. Oscillate for 2 min, centrifuge at 4000 r/min for 10 min at room temperature.
- (2) Take 250 μL of the supernatant to another tube, then add 750 μL of **Reconstitution Buffer** (Solution 2) to dissolve it.
- (3) Take 50 μL for analysis.

Note: Sample dilution factor: 8, detection limit: 0.8 ppb

3.2 Pretreatment of honey sample:

- (1) Weigh 1 ± 0.05 g of honey samples into a centrifuge tube. Then add 2 mL of **1% Trichloroacetic acid Solution** (Solution 1). Oscillate for 2 min, centrifuge at 4000 r/min for 10 min at room temperature.
- (2) Take 100 μ L of the supernatant to another tube. Add 1900 μ L of **Reconstitution Buffer** (Solution 2). Mix for 30s.
- (3) Take 50 μ L for analysis.

Note: Sample dilution factor: 40, detection limit: 4 ppb

3.3 Pretreatment of urine (swine) sample:

- (1) Take urine samples centrifuge at 4000 r/min for 10 min at room temperature.
- (2) Dilute clear urine samples with **Reconstitution Buffer** (Solution 2) for 10 times. (Urine: Reconstitution Buffer (Solution 2) (V) = 1:9).
- (3) Take 50 μ L for analysis.

Note: Sample dilution factor: 10, detection limit: 1 ppb

Assay procedure

Restore all reagents and samples to room temperature before use. All the reagents should be mixed thoroughly by gently swirling before pipetting. Avoid foaming. The unused ELISA Microtiter plate should be sealed as soon as possible and stored at 2~8°C.

Prepare the Standard Liquid. Standard Liquid of low concentration is unstable, prepare fresh solution before use.

Take 3 mL of **Reconstitution Buffer** (Solution 2) into **0 ppb bottle**. Take 2 mL of **Reconstitution Buffer** (Solution 2) into **0.1 ppb bottle, 0.3 ppb bottle, 0.9 ppb bottle, 2.7 ppb bottle** respectively. Take 3 mL of **Reconstitution Buffer** (Solution 2) into **8.1 ppb bottle**.

- (1) **Standard Liquid 6:** Take 24.3 μ L of **High Concentrated Standard (1.0 ppm)** into 8.1 ppb bottle, then mix fully. The concentration of Standard Liquid 6 is 8.1 ppb.
- (2) **Standard Liquid 5:** Take 1 mL of Standard Liquid 6 into 2.7 ppb bottle, then mix fully. The concentration of Standard Liquid 5 is 2.7 ppb.
- (3) **Standard Liquid 4:** Take 1 mL of Standard Liquid 5 into 0.9 ppb bottle, then mix fully. The concentration of Standard Liquid 4 is 0.9 ppb.
- (4) **Standard Liquid 3:** Take 1 mL of Standard Liquid 4 into 0.3 ppb bottle, then mix fully. The concentration of Standard Liquid 3 is 0.3 ppb.
- (5) **Standard Liquid 2:** Take 1 mL of Standard Liquid 3 into 0.1 ppb bottle, then mix fully. The concentration of Standard Liquid 2 is 0.1 ppb.
- (6) **Standard Liquid 1:** Use Reconstitution Buffer directly. The concentration of Standard Liquid 1 is 0 ppb.

- 1. Number:** number the sample and standard in order (multiple well), and keep a record of standard wells and sample wells. **Standard and Samples need test in duplicate.**
- 2. Add Sample:** add 50 µL of **Standard or Sample** per well, then add 50 µL **Antibody Working Solution**, cover the plate with plate sealer. Oscillate for 5s gently to mix thoroughly. Incubate at 37°C for 30 min in shading light.
- 3. Wash:** uncover the sealer carefully, remove the liquid in each well. Immediately add 300 µL of **Wash Buffer** (Solution 3) to each well and wash. Repeat wash procedure for 5 times, 30s intervals/time. Invert the plate and pat it against thick clean absorbent paper (If bubbles exist in the wells, clean tips can be used to prick them).
- 4. HRP Conjugate:** add 100 µL of **HRP Conjugate** to each well. Incubate at 37°C for 30 min in the shading light.
- 5. Wash:** Repeat step 3.
- 6. Color Development:** add 50 µL of **Substrate Reagent A** to each well, and then add 50 µL of **Substrate Reagent B**. Gently oscillate for 5s to mix thoroughly. Incubate at 37°C for 15 min in shading light (The reaction time can be extended according to the actual color change).
- 7. Stop Reaction:** add 50 µL of **Stop Solution** to each well, gently oscillate for 5s.
- 8. OD Measurement:** determine the optical density (OD value) of each well at 450 nm (reference wavelength 630 nm) with a microplate reader. This step should be finished in 10 min after stop reaction.

Result analysis

- 1. Absorbance (%) = $A/A_0 \times 100\%$**

A: Average absorbance of standard or sample

A₀: Average absorbance of 0ppb Standard

- 2. Drawing and calculation of standard curve**

Create a standard curve by plotting the absorbance percentage of each standard on the y-axis against the log concentration on the x-axis to draw a semi-logarithmic plot. Add average absorbance value of sample to standard curve to get corresponding concentration. **If samples have been diluted, the concentration calculated from the standard curve must be multiplied by the dilution factor.**

For this kit, it is more convenient to use professional analysis form for accurate and fast analysis of batch samples.

Notes

1. The overall OD value will be lower when reagents have not been brought to room temperature before use or room temperature is below 25°C.
2. If the wells turn dry during the washing procedure, it will lead to bad linear standard curve and poor repeatability. Operate the next step immediately after wash.
3. Mix thoroughly and wash the plate completely. The consistency of wash procedure can strongly affect the reproducibility of this ELISA kit.
4. ELISA Microplate should be covered by plate sealer. Avoid the kit to strong light.
5. **Each reagent is optimized for use in the E-FS-E024. Do not substitute reagents from any other manufacturer into the test kit. Do not combine reagents from other E-FS-E024 with different lot numbers.**
6. Substrate Reagent should be abandoned if it turns blue color. When OD value of standard (concentration: 0) < 0.5 unit (A450nm < 0.5), it indicates the reagent may be deteriorated.
7. Stop solution is caustic, avoid contact with skin and eyes.
8. As the OD values of the standard curve may vary according to the conditions of the actual assay performance (e.g. operator, pipetting technique, washing technique or temperature effects), the operator should establish a standard curve for each test.
9. Even the same operator might get different results in two separate experiments. In order to get reproducible results, the operation of every step in the assay should be controlled.
10. If the samples are not indicated in the manual, a preliminary experiment to determine the validity of the kit is necessary.
11. The kit is used for rapid screening of actual samples. If the test result is positive, the instrument method such as HPLC, LC/MS, etc. can be used for quantitative confirmation.

Storage and expiry date

Store the kit at 2~8°C. Do not freeze any test kit components.

Return any unused microwells to their original foil bag and reseal them together with the desiccant provided and further store at 2 - 8 °C.

Expiry date: expiration date is on the packing box.